

Fast Retrieve Fishing Rod Holder – Installation Instructions

1. Choose the location you would like to mount the trac. Be sure there will be enough room to accommodate your longest fishing rod.
2. Mark the location for the bottom first trac. It is best to plan for at least (1) screw to mount into a stud, but using drywall anchors are acceptable if required.
3. Screw in the set screws into the rings and j-hooks prior to sliding them into the trac. It is easiest to do this by hand from the underside of the ring or j-hook until almost flush.
4. Slide the rings and j-hooks into the trac and tighten with allen wrench when in proper location. Be sure to leave access to mounting holes in trac and tighten set screws after mounted to wall.
5. Mount trac to wall or ceiling with #8 screws (not included). Use the proper screw type for your mounting surface (drywall, wood, concrete, etc)
6. Place one of your shorter fishing rods in the ring and note where the j-hook should go. Mark the second trac location accordingly.
7. Mount the second trac and secure remaining set screws.
8. Load rods with reels on or if you wish to keep the reels off and mounting vertical, position the lower trac so the rod butt rests on the ground.

At Augsut 3, 2018