

Smart Airless DLX Cart

SKU 22-0044

Use with Kayaks, Canoes and SUP's

Updated January 2013



| Item # | Parts List | Qty |
|--------|--------------------|-----|
| 1 | Cart Frame | 1 |
| 2 | Straps Set | 2 |
| 3 | Airless Wheels | 2 |
| 4 | Quick-Release Pins | 2 |
| 5 | Mesh Storage Bag | 1 |

Assembly:

1. Unfold frame.
2. Slide on tires.
3. Install Quick-Release Pins in hole next to tire and flip the lock ring over the end of the frame to secure the tires in place.

Using the Smart Airless DLX Cart:

1. Unfold cart including the dual kickstand.
2. With the cart on the ground supported by the kickstands, position the cart under center of the boat.
3. Loop each set of straps around boat, pull tight. Don't cross or over-tighten strap!
4. Lift one end of the boat and kick the kickstands up and away you go.
5. Max weight is 150 lbs, this includes boat and all gear in boat. Do not overload cart.

Care:

1. Rinse cart after each use to clean off sand, salt and mud.
2. Store wheels, frame and straps in Mesh Storage Bag when not in use.

Warnings:

Straps

When putting straps around the boat make sure the non-marring buckle protection fabric is under the buckle before pulling strap tight. Do not pull straps too tight when connecting the cart to the boat; this could result in damage to the boat.

This cart is not intended to be pulled behind a motorized vehicle.

Our Pledge to you:

Suspenz products are guaranteed against defects in material and workmanship to the original owner for one year after purchase. Please contact Suspenz with any questions.

Toll-free: 866.787.7369
Fax: 770.518.8507
Email: info@suspenz.com

Contact Information
suspenz.com

Suspenz, Inc.
8725 Roswell Road #O-220
Atlanta, GA 30350

KAYAK-CANOE-SUP
storage & transport

SUSPENZ®