



**SPAREHAND<sup>®</sup> paddlesports**  
Display and Storage System

**PS-41L Single SUP Dual Angle Wall Rack**

**Caution – Failure to follow these guidelines can result in property damage or personal injury.**

- Parts are not labeled. Before assembly, please identify each part according to the descriptions and diagrams below.
- Do not use if the product or any parts is defective.
- Do not tilt or lift the storage rack.
- Do not drop SUP, Surfboard or any object on the rack. Place objects carefully and slowly.
- Do not step, stand, or climb on the storage unit.
- Do not use if loads are not balanced and / or cannot be used on level and secure ground. Always make sure the rack will not tip over. Secure the rack to the wall or floor if necessary.
- Use only if you determine the rack can be used safely.
- The manufacture and its agents are not responsible for any damages or injuries caused by the use or misuse of the product.
- Please follow the instructions and observe weight and size limits. 80 Lbs and 16 feet product length total maximum load. Load and size limits are per pair of cradles.
- Max weight varies depending on your wall and mounting method. In some situations, the max weight may be significantly lower.
- When moving the storage rack, remove all objects from the rack.
- For technical support or questions regarding this product, please contact 626-338-8998. PST 9:00 AM to 3:00 PM.

**Parts List PS-41L**

**The following parts are for each set of PS-41L Double SUP Rack**

- A. Vertical Wall Tube (2 PCS)
- B. Padded "Dual Angle" Cradle arms (2 PCS)

## Hardware:



**W:** Long screw  
M6 x 80 mm  
(2 PCS)


**X:** Short Screw  
(2 pcs)

## Installation Procedure:


- Step 1. Locate Wall Stand
- Step 2. Mount Part A to the wall and screw in with Short Screw (x) and long screws (W)  
The screw must go thru Part A (Flat side must be toward the wall)  
Screws must be secured to stud.  
**\*\*Do not install in Hollow walls\*\***
- Step 3. Install 2<sup>nd</sup> wall unit with proper spacing according to the gears to be stored.
- Step 4. Align and install Part B to Part A
- Step 5. **Dual Angle:** Rotate part B to get different angle application.  
Remove Cradle Arm, rotate to change angle, and re-insert cradle arm.
- Step 6. Use appropriate anchors when installing on block wall or brick walls.
- Step 7. Use foam tape to protect as necessary.

**This product may be used for, Paddle Board (SUP),  
Surfboard, Skis, Snowboard, Water Skis and other similar  
devices.**

**Parts:**




**Installation:**



**SPAREHAND® Systems, USA**      Tel: 626-338-8998  
[www.sparehand.net](http://www.sparehand.net)      [info@sparehand.net](mailto:info@sparehand.net)

Packaged and Printed in USA

## Dual Angle Application



SPARTEK® STAINLESS STEEL  
15001 E. 1st Ave. Suite 100, Denver, CO 80231  
www.spartek.com  
Packaged and Printed in USA