

# **Assembly, Installation, Care and Use Instructions** R10-1001, Kayak / SUP Dock Storage Rack System

#### Application

Dock mounted Kayak / SUP storage rack

# Assembly / Installation

Determine desired mounting location on dock Assembling rack's main frame & base support arms Make sure main upright's side support mounting plate is positioned on the inside of assembly. Place vertical upright in desired location. Mark (8) mounting hole locations. Place 2<sup>nd</sup> upright at desired distance and repeat steps.

#### Attaching to dock

Note: leave approximately 6" from back of vertical upright's mounting plate for vertical support upright installation. Drill (8) small pilot holes at marked mounting hole locations prior to installation. Using (8) 14 x 1 1/2" Truss head screws, attach assembly to dock and securely tighten. Installation tools required. Verify alignment and spacing; repeat steps for 2<sup>nd</sup> main vertical upright installation.

Fit base support arm's attachment bracket over vertical upright and insert (2) supplied 1/2-20 x 1 1/2" button socket cap screws. Mark (4) mounting hole locations. Remove fasteners and place assembly aside. Drill (4) small pilot holes at marked hole locations. Reattach support arm with fasteners and secure using (2) supplied 1/2-20 nylock nuts, a 7/16 wrench and the supplied 5/32 hex key wrench. Repeat steps for 2<sup>nd</sup> support arm.



Align connection brackets with vertical uprights and insert the supplied 1/20 x 2" button socket cap screws. Mark each supports (4) mounting plate holes, set support aside, and drill small pilot holes. Using supplied (8) 1/4" x 1 1/2" lag screws attach both support uprights to dock and securely tighten

Attach vertical support uprights to rack

Align support upright's connection bracket with rack's frame assembly. Slightly pulling rack towards vertical support upright until connection bracket is aligned, insert (1) spacer washer on each side between upright and bracket, and install (1) 1/4-20 x 2" Button socket cap screw through connection bracket / spacer washers / vertical upright and secure with (1) 1/4-20 nylock nut using a 7/16 wrench and supplied 5/32 hex key wrench. Repeat steps for 2<sup>nd</sup> vertical support Note: spacer washer's are not required if a kayak / SUP storage arm is to be mounted in that hole location.

# Securing equipment to rack (securing tie-down straps' not included)

Attach tie-down strap to rack's arm connection at the main frame, extend over equipment, and attach strap's hook to tie-down

#### Care and Use

- Kayak's and SUP's should be secured to rack when not in use
- Periodically wash rack with environmentally friendly, fresh water, and a clean cloth to remove any debris, wipe dry
- Water toys should always be rinsed with fresh water before storing

#### \*\*\*\*\*Original Proof of Purchase Required for all Warranty Claims\*\*\*\*

### **Limited Warranty**

Magma Products, Inc. guarantees this product to be free from defects in materials and workmanship for 1 year from the date of purchase to the original consumer. This guarantee is for the periods herein specified when used under normal and reasonable conditions in a non-commercial or non-institutional environment.

# **Conditions of Warranty**

This warranty does not include the cost of property damage or any inconvenience due to failure of the product. Nor does it cover damage due to misuse, accident, or damage resulting from transportation of this product. Nor does it include damage resulting from commercial / industrial use of this product. If the product fails to function due to a defect in materials or workmanship during the warranty period, the defective part will be repaired or replaced at Magma's option. If you wish to obtain performance under this limited warranty, you should contact Magma's Customer Service Department via telephone at 562-627-0500, e-mail at mail@magmaproducts.com, or U.S. Postal Service Mail at "Magma Products, Inc., Attention Customer Service, 3940 Pixie Ave., Lakewood, CA 90712 U.S.A." The defective part, along with proof of purchase, must be returned postage prepaid to Magma Products, Inc.

In the state of California only, if refinishing or replacement is not commercially practicable, the retailer selling the product, or Magma Products, Inc., will refund the purchase price paid for the product, less the amount directly attributable to use by the original consumer prior to the discovery of the nonconformity. In addition, in the state of California only, you may take the product to the retail establishment from which it was purchased or to any retail establishment selling this product in order to obtain performance under

ALL IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE EXPRESS WARRANTY PERIODS SPECIFIED HEREIN FOR THE PARTS DESCRIBED HEREIN.

Some states do not allow limitations on how long an implied warranty lasts. So the above limitation may not apply to you. Neither Magma dealers, nor the retail establishment selling this product has any authority to make any warranties or to promise remedies in addition to or inconsistent with those stated above. Magma's maximum liability shall not exceed the purchase price of the product paid by the original consumer. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. The warranty gives you specific legal rights and you may also have other.



#### Contents

- 1 ½" x 64" Stainless Steel main vertical upright

2 – 1" Stainless Steel vertical support upright 2 – 1 ½" x 30" Stainless Steel base support arm

32 – 14 x 1 ½" Stainless Steel Truss head screws 4 – ¼-20 x 1 ½" Stainless Steel button socket cap screw

2 - 1/4-20 x 2" Stainless Steel button socket cap screw

6 - 1/4-20 Stainless Steel nylock nut

Stainless Steel washer, spacer 1 - 5-/32 hex key wrench

#### **Tools Required**

7/16 wrench

Philips head screw driver

Additional Tools Required for Complete Installation





