


▲ TEAL TRIANGLE



INSTALLATION GUIDE FREESTANDING FISHING RACK



SCAN THIS QR CODE FOR
THE FULL INSTALL VIDEO.

IMPORTANT INFORMATION

Freestanding Fishing Rack

Quantity: 1

WARNING! The Freestanding Fishing Rack is NOT intended for use by any person under the age of 18 years old. You must be over the age of 18 to install or use the Freestanding Fishing Rack.

WARNING! Strictly follow all instructions to avoid an accident, damage to property, personal injury or death.

WARNING! Do not use this product for human suspension. Components can fail causing person to fall, possibly resulting in serious injury or death.

WARNING! When operating system, make sure the area below object is clear of persons. If object comes down too quickly, this can cause an accident.

READ THE ENTIRE USER MANUAL BEFORE INSTALLATION

The User Manual you received with your Freestanding Fishing Rack provides instructions on how to install and use your Freestanding Fishing Rack. The instructions are written for a person with a basic understanding of tools and procedures. Read the entire manual before proceeding. If you do not understand any portion of the instructions, do not attempt installation, and email support@tealtriangle.com.

CORRECTLY INSTALL THE PRODUCT

Read and follow all instructions carefully.

Failure to properly install and use the Freestanding Fishing Rack could allow the product to dismantle or tip over, injuring persons or personal property in the process. Accordingly, it is critical that the Freestanding Fishing Rack be installed correctly and according to the instructions in the User Manual.

USE TOOLS SAFELY

The procedures in the User Manual may require climbing ladders and/or operating power tools. Make sure you are familiar with these tools and their safety procedures before attempting to use such tools during installation. Always be aware of electrical wires during installation. Failure to do so could result in an electrical shock or death.

WARNING!

Contact with wires can give you a severe electrical shock, which may cause injury or death. If you do not know where wires are, have the work done by an experienced professional.

IMPORTANT INFORMATION

CAUTION

It is the consumer's responsibility to install this system in accordance with all codes, ordinances, and local regulations.

When installing the Freestanding Fishing Rack, it is the consumer's responsibility to ensure the structural integrity of the structure it is being mounted to.

The Freestanding Fishing Rack is intended for the storage of sporting goods only. Do not use it for any other purpose.

This system has a maximum capacity of 140 lbs. Overloading the system could result in damage to property or injury.


Use extreme caution when loading and unloading equipment from this system.

It is the consumer's responsibility to ensure that the system is in proper working condition before loading objects onto the system. Check tightness of all bolts and screws periodically. Failure to properly maintain the system could result in damage to property or injury.


WARNING AND DISCLAIMER

Spire LLC (d/b/a StoreYourBoard) expressly disclaims any and all liability for personal injury, property damage or loss, whether direct, indirect, incidental, resulting from the incorrect mounting, improper use, inadequate maintenance, or neglect of this system.

INSTALLATION



INCLUDED HARDWARE/TOOLS:



RECOMMENDED TOOLS:


3mm Allen Key (Included)
Phillips Screwdriver

WEIGHT LIMITS:

30 lbs. Per Shelf (A,B,D)
25 lbs. Per Rod Rest Plate (G)
140 lbs. total system weight

*weight must be evenly distributed

1 Start by laying out the Upper Uprights (E), Leg Braces (H), and Lower Uprights (F). Note that the Upper Uprights (E) and the Lower Leg Braces (H) are the exact same, with the Lower Uprights (F) having holes on the side.




E

H


F

2 Thread four M5 Connectors (K) onto four Lower Uprights (F) and tighten by hand. Put (K) through a hole in the Middle Shelf (B) and screw the Upper Upright (E) to the end of the M5 Connector (K). Tighten by hand and make sure that the three holes in the Lower Upright (F) are facing outwards.




Make sure the three holes in the Lower Uprights (F) are facing outwards after tightening.

3 Insert the two Leg Braces (H) into the Wire Shelf (D).




4 Using four M5 x 25mm Buttonhead Screws (J), connect the Rod Rest Plate (G) to the Leg Braces (H).



Note: The Wire shelf can be used as either a basket (as seen above) or flipped upside down for use as a flat surface.

5 Connect the two Rod Holders (C) to the threaded holes in the Lower Uprights (F) using four M5 x 10mm Buttonhead Screws (L). Fasten the Top Shelf (A) to the Upper Uprights (E) using four M5 x 20mm Flathead Screws (I).



Note: The height of the Rod Holder (C) can be moved to either threaded hole depending on the desired height.