

# INSTALLATION GUIDE

## WHEELREST BIKE HOOK



SCAN THIS QR CODE FOR  
THE FULL INSTALL VIDEO.

Questions or Concerns?

Contact us at:  [info@storeyourboard.com](mailto:info@storeyourboard.com)

# **IMPORTANT INFORMATION**

---

WheelRest Bike Hook

Manufactured for Spire LLC in Vietnam

Quantity: 1

**WARNING! The product is NOT intended for use by any person under the age of 18 years old. You must be over the age of 18 to install or use the product.**

**WARNING! Strictly follow all instructions to avoid an accident, damage to property, personal injury or death.**

## **READ THE ENTIRE USER MANUAL BEFORE INSTALLATION**

The User Manual you received with your product provides instructions on how to install and use your product. The instructions are written for a person with a basic understanding of tools and procedures. Read the entire manual before proceeding. If you do not understand any portion of the instructions, do not attempt installation, and email us with the information on the cover.

## **CORRECTLY INSTALL THE PRODUCT**

Read and follow all instructions carefully.

Failure to properly install and use the product could allow the product to dismantle or fall, injuring persons or personal property in the process. Accordingly, it is critical that the product be assembled and installed correctly and according to the instructions in the User Manual.

## **USE TOOLS SAFELY**

The procedures in the User Manual may require climbing ladders and/or operating power tools. Make sure you are familiar with these tools and their safety procedures before attempting to use such tools during installation. Always be aware of electrical wires during installation. Failure to do so could result in an electrical shock or death.

## **CAUTION**

It is the consumer's responsibility to install this system in accordance with all codes, ordinances, and local regulations.

When installing the product, it is the consumer's responsibility to ensure the structural integrity of the structure it is being mounted to.

The product is intended for the storage of sporting equipment only. Do not use it for any other purpose.

This system has a maximum capacity stated in the following section. Overloading the system could result in damage to property or injury.

Use extreme caution when loading and unloading equipment from this system.

It is the consumer's responsibility to ensure that the system is in proper working condition before loading objects onto the system. Check tightness of all bolts and screws periodically. Failure to properly maintain the system could result in damage to property or injury.

## **WARNING AND DISCLAIMER**

Spire LLC (d/b/a StoreYourBoard) expressly disclaims any and all liability for personal injury, property damage or loss, whether direct, indirect, incidental, resulting from the incorrect mounting, improper use, inadequate maintenance, or neglect of this system.


# WHEELREST PARTS

## WEIGHT LIMITS:

Bike weight limit is 75 lbs  
(floor holds most of the weight)

## REQUIRED TOOLS:


Drill/Driver  
Stud Finder  
1/16" (1.5mm) Drill Bit  
Phillips Head Screw Driver  
Level



# INSTALLATION STEPS

## 1 Measure your bike

Push your back wheel against a wall and measure from the wall to where your front wheel meets the ground. This is roughly the height you will mount the wall plate.




## 2 Locate the Studs and Mark the Wall Plate Holes

Use a stud finder to identify a wall stud where you will mount the wall plate. Measure the mounting height from the floor and mark it at the center of the stud. Hold the Wall Plate (A) against the wall at the marked location and mark the two mounting holes in the center of the stud.

## 3 Install the Wall Plate


Use a 1/16" (1.5mm) drill bit to drill pilot holes where you marked them. Install the Wall Plate using Wall Screws.






## Install the Tube and Hook

Use a Phillips Head Screwdriver to secure the Tube (B) to the Wall Plate (A) with 2 Phillips Head Screws (F) and Lock Washers (G). Begin with the tube aligned with the 2 holes in the Wall Plate as shown, and then adjust as needed.

Attach the Hook (C) to the Tube (B) using a Quick Pin (D), making sure the Quick Pin is fully inserted. Adjust as needed for the height of the bike.



**TO LOAD THE BIKE, LIFT THE HANDLEBARS AND ROLL THE BIKE TO THE WALL UNTIL THE FRONT WHEEL IS IN THE HOOK. TURN THE HANDLEBARS AND LET THE RIM AND TIRE REST BETWEEN THE SIDES OF THE HOOK. THE BACK WHEEL STAYS ON THE GROUND. THE HOOK ONLY KEEPS THE FRONT WHEEL FROM FALLING AND DOES NOT HOLD THE WEIGHT OF THE BIKE.**



**THE PRODUCT CAN BE ARRANGED IN DIFFERENT WAYS BASED ON YOUR NEEDS**

**THIS IS AN EXAMPLE OF AN ALTERNATE CONFIGURATION**

**THE HOOK IS IN THE OPPOSITE DIRECTION & HIGHER ON THE TUBE**

**THE TUBE IS MOUNTED HIGHER ON THE WALL PLATE**

**FLOOR**